



Technical Tip #155 – Cut-Off Burr Reduction

To reduce burrs:

- Use left-handed or right-handed inserts at slower feed rates.
- Pre-chamfer the workpiece, both externally and internally.
- Holder should be on center or .005" to .015" above centerline.
- If using a neutral insert, use the most narrow width possible.